


## The Centec Group

Centec is a privately owned group of companies. Based on extensive know-how, we are a specialist for automated process skids for high precision dosing – even of smallest quantities. For media supply we offer water purification and pure steam generation systems. CIP- and SIP-units designed and manufactured by Centec are widely used in chemical industries. Centec technology includes a range of high precision process sensors for accurately measuring critical product properties such as the concentration of acidic and caustic solutions and O<sub>2</sub> content. The largest chemical groups in the world are among our key customers.



**Accuracy. Reliability. Centec.**

### Germany

Centec GmbH  
Wilhelm-Röntgen-Strasse 10  
63477 Maintal  
Tel.: +49 6181 18 78 0  
Fax: +49 6181 18 78 50  
info@centec.de

### Czech Republic

Centec automatika s.r.o.  
Pekařská 8/601  
155 00 Praha 5  
Tel.: +420 257 084 111  
Fax: +420 235 518 701  
prodej@centec.cz

### USA

Centec LLC  
P. O. Box 820  
Germantown, WI 53022-0820  
Tel.: +1 262 251 8209  
Fax: +1 262 251 8376  
info@centec-usa.com

### UK

Centec UK  
Stalworths, The Street  
Great Tey, Colchester, Essex, CO6 1JS  
Tel.: +44 1206 21 19 21  
Fax: +44 1206 21 19 16  
info@centec-uk.com

### Serbia

Centec Serbia  
Bogdana Žerajića 34/III  
11000 Beograd  
Tel.: + 381 11 358 11 24  
Fax: + 381 11 358 11 24  
info@centec.rs

### India

Centec RRR Systems & Sensors Pvt Ltd  
RRR House, Plot 80, Sector 23  
Turbhe Naka, Navi Mumbai - 400 705  
Tel.: +91 22 2783 3655 & 2783 1348  
Fax: +91 22 2783 4814  
mail@centecrrr.com

### Brazil

Centec América Latina Ltda  
Rua Mexico 148 conj. 1004 Centro  
20031 142 Rio de Janeiro  
Tel.: +55 21 2223 2066  
centelatina@terra.com.br

**DeGas-H**

**Hot Column Deaeration**

**Centec Chemistry Systems**



Automated  
process skids  
and high precision  
sensors from a  
single source.  
**Centec.**

# DeGaS-H

## The Principle

The Centec column deaeration system DeGaS-C is a modular skid for removing oxygen from water heated to about 75 °C. The presence of even low O<sub>2</sub> levels can cause serious corrosion damage by forming oxides. For treatment in DeGaS-C, the liquid is injected at the top of the column. The column contains a matrix of structured packing comprising thin corrugated metal plates arranged so that the liquid takes multiple paths as it flows downwards through the column. This maximizes the transfer surface and the contact time between the liquid and the strip gas; CO<sub>2</sub> or N<sub>2</sub> may be used. The strip gas is fed into the bottom and flows upwards inside the column. The large partial pressure difference of O<sub>2</sub> forces the oxygen out of the liquid into the gas phase. This fundamental scientific principle is described by "Henry's Law". At the top of the column the removed O<sub>2</sub> leaves the system together with the undissolved CO<sub>2</sub> or N<sub>2</sub>. The resultant deaerated liquid is slightly carbonated or nitrogenated depending on the strip gas used. O<sub>2</sub> content monitoring can be done with accurate OXYTRANS optical sensing technology developed and manufactured by Centec.

## Technical Data

Capacity	1 - 200 m <sup>3</sup> /h
Residual Oxygen	< 10 ppb
Pressure of Operation	0 - 8 bar
Temperature of Operation	8 - 95 °C
Temperature of CIP	max. 95 °C
Material	1.4301/1.4404 AISI 304/316L
Heating Medium	steam
Cooling Medium	glycol, ice water, ammonia, brine
PLC	SIMATIC S7
Options	in-line O <sub>2</sub> measurement pre-filtration disinfection



The Centec production is certified according to ISO 9001.

- **Application Specific and Energy Efficient**  
reduced solubility of oxygen in hot water  
simultaneous disinfection of liquid  
excellent heat regeneration performance
- **Modular Design with Standard PLC**  
skid mounted for easy installation and start-up
- **Hygienic Execution and Full CIP Capability**
- **Outstanding Price-Performance-Ratio**

## Experience. Expertise. Centec.

Particle Pre-Filtration · Disinfection · Water Softening & Demineralization · Ultrafiltration · Reverse Osmosis  
Electro Deionization · WFI Distillation · Membrane Deaeration · Column Deaeration · Vacuum Deaeration  
Multi Component Mixing · Additive Dosing · Flash Pasteurization · Cleaning-in-Place · Pure Steam Generation

