


The Centec Group

Centec is a privately owned group of companies. Based on extensive know-how, we are a specialist for automated process skids for high precision dosing – even of smallest quantities. For media supply we offer water purification and pure steam generation systems. CIP- and SIP-units designed and manufactured by Centec are widely used in chemical industries. Centec technology includes a range of high precision process sensors for accurately measuring critical product properties such as the concentration of acidic and caustic solutions and O₂ content. The largest chemical groups in the world are among our key customers.



Accuracy. Reliability. Centec.

Germany

Centec GmbH
Wilhelm-Röntgen-Strasse 10
63477 Maintal
Tel.: +49 6181 18 78 0
Fax: +49 6181 18 78 50
info@centec.de

Czech Republic

Centec automatika s.r.o.
Pekařská 8/601
155 00 Praha 5
Tel.: +420 257 084 111
Fax: +420 235 518 701
prodej@centec.cz

USA

Centec LLC
P. O. Box 820
Germantown, WI 53022-0820
Tel.: +1 262 251 8209
Fax: +1 262 251 8376
info@centec-usa.com

UK

Centec UK
Stalworths, The Street
Great Tey, Colchester, Essex, CO6 1JS
Tel.: +44 1206 21 19 21
Fax: +44 1206 21 19 16
info@centec-uk.com

Serbia

Centec Serbia
Bogdana Žerajića 34/III
11000 Beograd
Tel.: + 381 11 358 11 24
Fax: + 381 11 358 11 24
info@centec.rs

India

Centec RRR Systems & Sensors Pvt Ltd
RRR House, Plot 80, Sector 23
Turbhe Naka, Navi Mumbai - 400 705
Tel.: +91 22 2783 3655 & 2783 1348
Fax: +91 22 2783 4814
mail@centecrrr.com

Brazil

Centec América Latina Ltda
Rua Mexico 148 conj. 1004 Centro
20031 142 Rio de Janeiro
Tel.: +55 21 2223 2066
centeclatina@terra.com.br

VeGas

Vacuum Deaeration

Centec Chemistry Systems



Automated
process skids
and high precision
sensors from a
single source.
Centec.

VeGaS

The Principle

The Centec vacuum deaeration system VeGaS is a modular skid using a vacuum vessel for the removal of oxygen and other gases from a wide range of liquids. The presence of even low oxygen levels can cause serious corrosion damage by attaching to metal piping and other metallic equipment and forming oxides. Through special dispersion nozzles the liquid is sprayed into a continuously evacuated vessel. Due to the distribution of the fine liquid droplets, the transfer surface area between the liquid and the vacuum is maximized. The large partial pressure difference of O₂ forces the oxygen out of the liquid into the vacuum. This fundamental scientific principle is described by "Henry's Law". Once the oxygen has been removed, it transfers out of the vessel through the vacuum line. The deaerated product collects at the bottom of the tank from where it is discharged for further processing. Vacuum deaeration can be assisted by a strip gas like nitrogen or carbon dioxide. O₂ content monitoring with highly accurate OXYTRANS optical sensing technology developed and manufactured by Centec can be added, as can various other options.

Technical Data

Capacity	2 - 180 m ³ /h
Residual Oxygen	< 10 ppb
Pressure of Operation	0 - 8 bar
Temperature of Operation	2 - 85 °C
Temperature of CIP	max. 85 °C
Material	1.4301/1.4404 AISI 304/316L
PLC	SIMATIC S7
Options	in-line O ₂ measurement pre-filtration disinfection



The Centec production is certified according to ISO 9001.

- **Application Specific and Energy Efficient**
extensive contact between liquid and vacuum
subsequent disinfection of liquid possible
- **Modular Design with Standard PLC**
skid mounted for easy installation and start-up
sturdy execution and customized design of vessel
- **Hygienic Execution and Full CIP Capability**
- **Outstanding Price-Performance-Ratio**

Experience. Expertise. Centec.

Particle Pre-Filtration · Disinfection · Water Softening & Demineralization · Ultrafiltration · Reverse Osmosis
Electro Deionization · WFI Distillation · Membrane Deaeration · Column Deaeration · Vacuum Deaeration
Multi Component Mixing · Additive Dosing · Flash Pasteurization · Cleaning-in-Place · Pure Steam Generation

